

USB Drive

System Configuration				
Device Configuration		Manufacturer	Model No.	Spec.
	Processor	AMD	Athlon™ 64 Processor 3200+	FSB 200 (Winchester)
	Memory	Apacer	SEC K4H560838D-TCB3	DDR333 / 512MB
	VGA Card	MSI	MS-8978	Radeon X700XT
	Lan Card	Onboard		
	Sound Card	Onboard		
	Hard Drive	Seagate	ST3160023AS	SATA150 / 160GB
	CD-ROM	SONY	CDU5211	52X
	Floppy Drive	TEAC	FD-235HF	1.44MB
	Power Supply	Seventeam	ST-300BLV	300W
	Mouse	Acer	M-S69	PS/2
	Keyboard	Acer	6511-CX	PS/2
	Monitor	ViewSonic	G810	19" CRT

USB 1.1

Type	Model		Plug/Play	Restart	STR (S3)	Result
			10X	5X	5x	
Camera	Huaerte	Web Eye PC-9	OK	OK	OK	OK
	Logitech	QuickCam IM (V-UAM27)	OK	OK	OK	OK
		QuickCam Messenger (V-UM14)	OK	OK	OK	OK
		QuickCam Sphere (V-UU22)	OK	OK	OK	OK
		QuickCam Zoom (V-UW21)	OK	OK	OK	OK
Card Reader	Transcend	TS0MFLRD6 (6-in-1 Card Reader/Writer)	OK	OK	OK	OK
Flash Drive	Apacer	Steno BP300 128MB	OK	OK	OK	OK
	MSI	MS-5511 MEGA STICK 128MB	OK	OK	OK	OK
	Transcend	TS256MJFLASHA (JetFlashA) 256MB	OK	OK	OK	OK
		TS128MJFLASHM (JetFlashM) 128MB	OK	OK	OK	OK
Floppy	IMATION	LKM-FK73-D	OK	OK	OK	OK
	Iomega	Z100USB ZIP	OK	OK	OK	OK
		Z250USB ZIP	OK	OK	OK	OK
		BXXU0130 USB Floppy Powered Drive	OK	OK	OK	OK
	NEC	UF0002	OK	OK	OK	OK
GamePad	Microsoft	Side Winder FreeStyle Pro	OK	OK	OK	OK
Joystick	GENIUS	Force Feedback F-33D	OK	OK	OK	OK
	Logitech	Wingman Force 3D (J-UC10)	OK	OK	OK	OK
		Wingman Formula Force GP (E-UD4)	OK	OK	OK	OK
	Microsoft	Side Winder Force Feedback 2	OK	OK	OK	OK
		Side Winder Precision Pro	OK	OK	OK	OK
Keyboard	BTC	Keyboard 5200 TU	OK	OK	OK	OK

	Cherry	210XX	OK	OK	OK	OK
		Cherry RS 6000 USB ON	OK	OK	OK	OK
	Logitech	Cordless Freedom Optical (Y-PJ20)	OK	OK	OK	OK
		Cordless MX Duo	OK	OK	OK	OK
		Internet Navigator Keyboard (Y-BF37)	OK	OK	OK	OK
	Microsoft	Basic Wireless Optical Desktop 1.1	OK	OK	OK	OK
		Natural Keyboard Pro	OK	OK	OK	OK
		Wireless Optical Desktop 1.0A	OK	OK	OK	OK
	Mouse	BenQ	M107	OK	OK	OK
Logitech			MX700 Cordless Optical Mouse (M-RY81)	OK	OK	OK
		Wheel Mouse (M-BQ85)	OK	OK	OK	OK
		Cordless Freedom Optical (Y-PJ20)	OK	OK	OK	OK
		Cordless MX Duo	OK	OK	OK	OK
		Cordless Optical Mouse (M-RM63)	OK	OK	OK	OK
MSI		CM1092	OK	OK	OK	OK
		MU8CX	OK	OK	OK	OK
Microsoft		Basic Wireless Optical Desktop 1.1	OK	OK	OK	OK
		IntelliMouse Optical	OK	OK	OK	OK
		IntelliMouse Explorer	OK	OK	OK	OK
		Wireless IntelliMouse Explorer	OK	OK	OK	OK
		Wireless Optical Desktop 1.0A	OK	OK	OK	OK
Printer		EPSON	PictureMate	OK	OK	OK
	Stylus Photo 895		OK	OK	OK	OK
	HP	Deskjet 1220C	OK	OK	OK	OK
		Photosmart 245	OK	OK	OK	OK
	Lexmark	X6150 4 Powerful Features in 1	OK	OK	OK	OK
		Lexmark P707 Color Jetprinter	OK	OK	OK	OK
Scanner	BenQ	S2W 5300U	OK	OK	OK	OK
	EPSON	Expression 1600 Scanner	OK	OK	OK	OK
	HP	LaserJet 1015	OK	OK	OK	OK
		Scanjet 4400C	OK	OK	OK	OK
		Scanjet 3570C	OK	OK	OK	OK
Speaker	Microsoft	Digital Sound System 80	OK	OK	OK	OK
Wireless LAN	PCI	GW-US11H (Wireless 802.11b)	OK	OK	OK	OK
	SMC	2664W (Wireless 802.11b)	OK	OK	OK	OK

USB 2.0

Type	Model		Plug/Play	Restart	STR (S3)	Result
			10X	5X	5x	
CD-RW	Aopen	EHW5224U (52R, 24RW)	OK	OK	OK	OK
	ASUS	CRW-5232AS-U (52x/32x/52x)	OK	OK	OK	OK
	BENQ	5224WU (52X/24X/52X)	OK	OK	OK	OK

	Iomega	External CD-RW (52X/24X/52X)	OK	OK	OK	OK
	MSI	MS-8352E (52X/24X/52X)	OK	OK	OK	OK
	Plextor	PX-W5232TU (52X/32X/52X)	OK	OK	OK	OK
Combo	Aopen	ESV-189U Pro (24X/10X/24X)	OK	OK	OK	OK
	Lite-On	LSC-24081MX (24X/12X/24X)	OK	OK	OK	OK
	TEAC	DW-224PUC-00 (24X/24X/24X)	OK	OK	OK	OK
Card Reader	Apacer	Disc Steno CP100	OK	OK	OK	OK
	Transcend	TS128MFLRD7(7-in-1 Card Reader/Writer)	OK	OK	OK	OK
DVD+RW	HP	DVDWriter DVD300E (4R/2.4RW/8R)	OK	OK	OK	OK
DVD-RW	Aopen	EHD2412U (2.4DVD+RW, 2.4DVD+R, 8X)	OK	OK	OK	OK
	Pioneer	DVR-SK12D (2R/2.4RW/8X) (USB2.0+IEEE1394)	OK	OK	OK	OK
DVD-Dual	LG	GSA-5120D (12R/4RW/16X) (USB2.0+1394)	OK	OK	OK	OK
	Lite-On	SDW-431SX (4R,2RW,8X)	OK	OK	OK	OK
	MSI	MS-8408E-A DVD Dual (8R,2RW,8X)	OK	OK	OK	OK
Hard Disk	Data FAB	MD3A-USB2A	OK	OK	OK	OK
	Iomega	External HDD 120GB	OK	OK	OK	OK
		Desktop HDD DHD120-C 120GB (USB2.0+IEEE1394)	OK	OK	OK	OK
	MacPower	IceCube Impt-3500FRUB2H (USB2.0+1394)	OK	OK	OK	OK
	Maxtor	Personal Storage 5000XT 250G(1394&USB2.0)	OK	OK	OK	OK
Flash Drive	Iomega	Mini 256MB	OK	OK	OK	OK
	MSI	MS-5511 MEGA STICK 511 128MB	OK	OK	OK	OK
		MS-5512 MEGA STICK 256 256MB	OK	OK	OK	OK
		MS-5521 MEGA Player 521 256MB	OK	OK	OK	OK
Floppy	Iomega	750 USB2.0 ZIP	OK	OK	OK	OK
Network	D-LINK	DUB-E100	OK	OK	OK	OK
	LinkSYS	USB200M	OK	OK	OK	OK
Printer	Canon	I905D	OK	OK	OK	OK
	HP	Photosmart 7660	OK	OK	OK	OK
Scanner	BenQ	S2W 5450	OK	OK	OK	OK
	Canon	CanoScan 3000	OK	OK	OK	OK
		CanoScan 5000F	OK	OK	OK	OK
	Epson	Perfection 1660 Photo Scanner	OK	OK	OK	OK
		Perfection 3200 Photo (USB2.0+1394)	OK	OK	OK	OK
	HP	HP Scanjet 4570C	OK	OK	OK	OK
Wireless LAN	3COM	3CRUSB10075	OK	OK	OK	OK
	Buffalo	WLI-U2-KG54	OK	OK	OK	OK
	SMC	SMC2862W-G	OK	OK	OK	OK