

USB Device

USB 1.1

Type	Model		Plug/Play	Restart	STR (S3)	Result
			10X	5X	5x	
Jovstick	Logitech	J-ZA10	OK	OK	OK	OK
	Logitech	J-UK17	OK	OK	OK	OK
Game Pad	Logitech	G-2B-PHI	OK	OK	OK	OK
	Logitech	G-UH21	OK	OK	OK	OK
遊戲方向盤	清華同方	J11S	OK	OK	OK	OK
	Logitech	E-EL13	OK	OK	OK	OK
FDD	MITSUMI	D353FUE	OK	OK	OK	OK
	SONY	MPF82E	OK	OK	OK	OK
Keyboard	Dell	SK-8135	OK	OK	OK	OK
	Dell	SK-8115	OK	OK	OK	OK
	BenQ	6511-UJ	OK	OK	OK	OK
	Logitech	Y-UV90	OK	OK	OK	OK
	Logitech	炫光鍵盤(Y-UY95)	OK	OK	OK	OK
	Viewsonic	VS10230	OK	OK	OK	OK
	雙飛燕	KBS-3	OK	OK	OK	OK
Mouse	BenQ	M800	OK	OK	OK	OK
	Logitech	MX510	OK	OK	OK	OK
	Logitech	MX310	OK	OK	OK	OK
	Logitech	M-BP82	OK	OK	OK	OK
	Microsoft	IntelliMouse Explorer 3.0 USB & PS/2	OK	OK	OK	OK
	Microsoft	光學精靈鯊 500 V2.0	OK	OK	OK	OK
	Microsoft	Basic Optical Mouse	OK	OK	OK	OK
Wireless Keyboard/Mouse	雙飛燕	KBS-1257RP	OK	OK	OK	OK
	Logitech	LX310	OK	OK	OK	OK
	Logitech	EX110	OK	OK	OK	OK
	Microsoft	Wireless Desktop 6000 V3	OK	OK	OK	OK
Printer	Canon	PIXMA iP1200	OK	OK	OK	OK
	Epson	EPL-6200L	OK	OK	OK	OK
	EPSON	STYLUS CX5500	OK	OK	OK	OK
Scanner	Canon	CanoScan LiDE 25	OK	OK	OK	OK
	HP	SCANJET G2410	OK	OK	OK	OK
Web Cam	Delux	DLV-B16	OK	OK	OK	OK
	Logitech	QuickCam Cool	OK	OK	OK	OK
	Logitech	Quickcam Connect	OK	OK	OK	OK
	Microsoft	Lifecam VX-3000	OK	OK	OK	OK
Sound Card	Creative	X-Fi Xmod	OK	OK	OK	OK
Speaker	Logitech	S-0194B	OK	OK	OK	OK
Cardreader	SSK	All in 1 Card Reader	OK	OK	OK	OK

USB 2.0

Type	Model		Plug/Play	Restart	STR (S3)	Result
			10X	5X	5x	
HDD	BenQ	DP302 (40GB)	OK	OK	OK	OK
	BenQ	DP308 (20GB)	OK	OK	OK	OK
	Seagate	ST3250824U2-RK	OK	OK	OK	OK
	Datastorage	PD-eSATA	OK	OK	OK	OK
	LACIE	Mini HUB HD(USB & 1394, 300GB)	OK	OK	OK	OK
	Cenda	C601(120GB)	OK	OK	OK	OK
	Founder	e 存 H1200(160GB)	OK	OK	OK	OK
	WD	My Book home Edition WD5000H1CS-00(500G)	OK	OK	OK	OK

	Seagate	FreeAgent Xtreme (1TB)	OK	OK	OK	OK
	Maxtor	Onetouch4 mini 320GB	OK	OK	OK	OK
	Seagate	FreeAgent Xtreme (1.5TB)	OK	OK	OK	OK
	Buffalo	BUF-BR-816SU2(B) (4*750GB)	OK	OK	OK	OK
Flash Memory	Kingmax	超棒 2GB	OK	OK	OK	OK
	Kingston	DataTraveler ReadyFlash 1GB	OK	OK	OK	OK
	Netac	U285(1GB)	OK	OK	OK	OK
	Lenovo	智存卡 3.0(2GB)	OK	OK	OK	OK
	Aigo	迷你王(精銳型 1GB II 代)	OK	OK	OK	OK
	Apacer	AH320(8GB)	OK	OK	OK	OK
	Teclast	酷閃晶彩(16GB)	OK	OK	OK	OK
	Eaget	CM960PRO(32GB)	OK	OK	OK	OK
	Eaget	CM960(16GB)	OK	OK	OK	OK
Web Cam	Logitech	Quickcam Deluxe for notebook	OK	OK	OK	OK
	Microsoft	LifeCam VX-6000	OK	OK	OK	OK
CD-RW	BenQ	5232W1	OK	OK	OK	OK
DVD RW	Teclast	DWB16PU	OK	OK	OK	OK
	PLEXTOR	PX-810UF	OK	OK	OK	OK
	LACIE	d2 DVD ± RW	OK	OK	OK	OK
	Buffalo	BUF-BR-816SU2(B)	OK	OK	OK	OK
WLAN	ASUS	WL-167g USB WLAN Adapter (54M)	OK	OK	OK	OK
	ALPHA	AFW-GU50 (54M)	OK	OK	OK	OK
	D-link	DWA-140 (54M)	OK	OK	OK	OK
	LINKSYS	WUSB54G Ver:4 (54M)	OK	OK	OK	OK
	TP-LINK	TL-WN322G+ (54M)	OK	OK	OK	OK
	TP-LINK	TL-WN620G (54M)	OK	OK	OK	OK
	BUFFALO	WLI-UC-G300N	OK	OK	OK	OK
TV Card	10Moons	UAD-TH200	OK	OK	OK	OK
Printer	SAMSUNG	SCX-4300	OK	OK	OK	OK
Scanner	EPSON	PERFECTION V10	OK	OK	OK	OK