

## CDROM

Model		Spec.	Boot from CD	Detect & Read data	CD WinBench 99
MSI	C52(MS-8152)	IDE; 52X; UDMA2	OK	OK	OK

## DVD ROM

Model		Spec.	Boot from CD	Detect & Read data	CD WinBench 99	VCD & DVD Play
MSI	D16(MS-8216)	IDE; 16X; UDMA2	OK	OK	OK	OK
SONY	DDU1621	IDE; 16X; UDMA2	OK	OK	OK	OK
ASUS	DVD-E616P3	IDE; 16X; UDMA5	OK	OK	OK	OK
Pioneer	DVD-122E	IDE; 16X; UDMA5	OK	OK	OK	OK
LG	GDR-8163B	IDE; 16X; UDMA2	OK	OK	OK	OK
LITEON	SOHD-167T	IDE; 16X; UDMA2	OK	OK	OK	OK
BenQ	1650V	IDE; 16X; UDMA5	OK	OK	OK	OK
源興	BDV316E	IDE; 16X; UDMA4	OK	OK	OK	OK
Pioneer	DVD-128D	IDE; 16X; UDMA5	OK	OK	OK	OK
BenQ	DD165G	IDE; 16X; UDMA2	OK	OK	OK	OK
ASUS	DVD-E818A	IDE; 16X; UDMA5	OK	OK	OK	OK
LG	GDR-H30N	IDE; 16X; UDMA2	OK	OK	OK	OK
SAMSUNG	TS-H353	SATA	OK	OK	OK	OK

## CD-RW

Model		Spec.	Detect & Read data	CD Copy
LITE-On	LTR-52327S	IDE;UDMA2	OK	OK
SONY	CRX230A	IDE;UDMA2	OK	OK

## Combo (CD-RW/DVD-ROM)

Model		Spec.	Detect & Read data	CD Copy
BenQ	CB523C	IDE;UDMA2	OK	OK
SAMSUNG	TS-H492	IDE;UDMA2	OK	OK
LG	GCC-4521B	IDE;UDMA2	OK	OK
SONY	CRX300A	IDE;UDMA2	OK	OK

## DVD Dual (DVD-RW/DVD+RW)

Model		Spec.	Detect & Read data	DVD Copy
SAMSUNG	TS-H552	IDE;UDMA2	OK	OK
LG	GWA-4164B	IDE;UDMA2	OK	OK
Plextor	PX-760A	IDE;UDMA4	OK	OK
Pioneer	DVR-111BXL	IDE;UDMA4	OK	OK
SAMSUNG	TS-H652	IDE;UDMA2	OK	OK
SAMSUNG	TS-H552	IDE;UDMA5	OK	OK
Pioneer	DVR-212CHG	SATAI	OK	OK
Asus	DRW-1814BLT	SATAI	OK	OK
Samsung	TS-H653	SATAI	OK	OK
LITE-ON	LH-2B1S	SATAI, Blue Ray	OK	OK
PHILIPS	SPD2413	IDE;UDMA2	OK	OK
LG	GSA-H55N	IDE;UDMA5	OK	OK
ASUS	DRW-1814BL	IDE;UDMA2	OK	OK
SAMSUNG	TS-H653	SATA	OK	OK