



How to turn off back led  
bar on both MAG241CR  
and MAG271CR/CQR?

如何在MAG241CR 及  
MAG271CR/CQR 上關掉螢幕背面  
之LED燈條?



SOME ARE PC, WE ARE GAMING TRUE GAMING

A stylized red dragon logo, facing right, with its mouth open showing sharp teeth. The dragon is rendered in a bold, graphic style with black outlines and a solid red fill.

*msi*

By OSD Joystick

透過OSD搖桿

TRUE  GAMING

## Step 1: Find the control joystick

### 控制搖桿之位置與操作模式



- The control joystick is on the back of your Monitor.
- The joystick may be either flicked or pushed.
- Move to the option you'd like to select by flicking the joystick and select it by pushing the joystick.
- Show OSD menu by pushing the joystick.


- 控制搖桿位於你螢幕的後方。
- 搖桿可以透過撥動或按壓的方式操控。
- 利用搖桿將選標移動至欲選之項目，按壓搖桿以將其選中。
- 按壓搖桿以叫出控制選單。



## Step 2: Turn off back led bar 關掉螢幕背面之LED燈條



- Go to OSD menu -> Setting -> RGB LED -> Choose "Off".
- Push joystick then check OFF item has be checked.
- 開啟控制選單->設定->RGB LED->選擇“關”。
- 按下搖桿確認關閉是否有被勾選





*msi*

By Gaming OSD tool

透過Gaming OSD軟體

TRUE  GAMING

# Step 1: Execution Mystic Light tool 執行Mystic Light 工具



- Double Click “Gaming OSD” icon on desktop or program file.(Please sure monitor’s USB cable connect to system)
- Click “Mystic Light” on Gaming OSD tool.
- 點選桌面或程式集中Gaming OSD圖示 (請確認螢幕之USB線有連接至電腦)
- 在Gaming OSD程式中點選右上方之Mystic Light功能。



## Step 2: Turn off back led bar 关掉螢幕背面之LED燈條



- Click LED Effects “OFF”.  
PS. If OSD set LED off, Mystic light can't change effect, until restart Mystic light or enable Led from OSD.
- 點選燈光效果“關閉”。  
PS. 若OSD設定關閉，Mystic light設定會失效，直到重新啟動Mystic light或是從OSD重新開啟LED。





***msi***<sup>®</sup>

**TRUE *G*AMING**  
SOME ARE PC, WE ARE GAMING